

FITTING INSTRUCTIONS TOYOTA 100 SERIES

Please ensure you read these instructions in their entirety prior to performing any of the steps below.

Please check all parts are supplied prior to commencement.

If you think a part is missing, please contact:

(03) 9736 4932

Or

sales@raslarr.com.au



(03) 9736 4932



sales@raslarr.com.au



5,122-130 Beresford Rd,
Lilydale VIC 3140

Vehicle:	TOYOTA LANDCRUISER 100 SERIES
Product:	RASLARR SLIDERS (TYLC100RS01)
Suits:	100 Series IFS

IMPORTANT – PLEASE READ BELOW

Raslarr Engineering have, as best we could, tried to provide clear and precise instructions for our products.

As always, we recommend persons with experience with these types of products and knowledge of the vehicle they are performing the fitment on.

Warranty can be voided due to incorrect installation of our products.

Raslarr assumes that the person performing the fitment is capable of fitting these products.

Raslarr will not be held liable for any damages that may occur by incorrect installation.

Hardware such as bolts, nuts, lights, pinchweld etc are provided for a **reason**. Should you have items left over, please double check your installation.

If there is an instructional video on YouTube, it is recommended to read these instructions in conjunction with the video.



(03) 9736 4932



sales@raslarr.com.au



5,122-130 Beresford Rd,
Lilydale VIC 3140

Step 1.

Remove original steps and discard.

On some vehicles, the inside exhaust mount may need to be removed and re-fitted at the end of the job.

Step 2.

Offer sliders to the vehicle using a trolley jack under the centre foot to balance and push the U around the chassis rail.

Leave this there until the slider is bolted.

Step 3.

Fit the 2 rear u bolts to the chassis.

Tighten, making sure the U's are all the way home to the bottom of the chassis.

Step 4.

Remove jack(s) and align slider parallel to the bottom of the sill, checking clearance.

Now it's time for the front foot to be clamped and pinned to the chassis out-rigger using the 12mm hardware supplied.

Step 5.

Tighten all bolts.

For further information regarding the fitment, or if you have any questions, please give us a call on (03) 9736 4932 within operating hours:

8am – 4pm MON – FRI

A full copy of the terms and conditions were emailed with your booking tax invoice.



(03) 9736 4932



sales@raslarr.com.au



5,122-130 Beresford Rd,
Lilydale VIC 3140